FIG.4




FIG.5

FUNCTION FLAG CDPWRF	BROADCAST RECEIVING	CD/CASSETTE/ LINE INPUTS (MD)
″1″	ON	ON
"0"	OFF	ON

POWER CONTROL OF CD PLAYER